

Smart Smoke Detector

User Instructions

1. Product Overview

The Smart Smoke Detector is a wireless device designed to detect smoke and alert you to fire hazards in your home. It communicates alerts via sound and mobile notifications.

2. Package Contents

- 1 Å— Smart Smoke Detector
- 2 Å— AA Batteries
- 1 Å— Mounting Kit
- 1 Å— User Instructions

3. Installation

1. Choose a suitable location on the ceiling (not near air vents).
2. Attach the mounting plate using the provided screws.
3. Insert the AA batteries into the detector.
4. Align and twist the detector onto the mounting plate.

4. Connecting to the App

1. Download the "Smart Smoke" app from the App Store or Google Play.
2. Follow the in-app instructions to create an account.
3. Add a new device and scan the QR code located inside the detector.
4. Complete setup to connect to Wi-Fi.

5. Operation

- The detector monitors air 24/7 for smoke particles.
- In the event of smoke, a loud alarm will sound and a notification will be sent to your phone.
- Test the alarm by pressing the "Test" button for 2 seconds. The alarm should sound briefly.

6. LED Indicator Guide

Status	LED Behavior	Description
Normal	Blinks once every minute	Device functioning properly
Smoke Detected	Flashing rapidly	Smoke alarm triggered
Low Battery	Flashes every 30 seconds	Replace batteries soon
Error	Constant light	Device malfunction, consult manual

7. Maintenance

- Test the device monthly.
- Replace batteries once a year or when notified.
- Clean with a dry cloth; do not use water or solvents.

8. Safety Notes

- This device is not a substitute for regular fire safety precautions.
- Do not install in areas subject to steam or extreme dust.
- Keep out of reach of children.

